

## **World Time Clock System (auto DLS feature)**

ROM# 796S102D.HEX

### **Clock Feature**

The clock is set via Remote Controller. The setting procedure is introduced as below.

#### **Setting Via Remote Controller**

##### **1. Date & Time Setting:**

The sequence of the Date & Time setting is:

*Display time – Year (4-digit) – Month & Day – Hour & Minute – Display time*

Press "LOCK"+"CLOCK" buttons under the Display mode, you will see 4-digit Year, and the 3<sup>rd</sup> digit of the year will flash for your entering with the right figure or you can use left (←) and right (→) button to move the flash cursors to the digit you want to update, while finishing the Date & Time setting, press "CLOCK" button again to quit the setting mode and go back to the Display mode.

##### **2. 12/24 Hour setting:**

In Date & Time setting mode (by pressing LOCK+CLOCK), use up (↑) and down (↓) button to select the desired hour circle; up (↑) presents 24 hours and down (↓) presents 12 hours. After setting, press CLOCK again to quit the mode.

##### **Note**

- 1. The World Time Clock is made with auto DLS feature, and the Daylight Saving Time period for each city has to be pre-set in factory and cant' be changed by user.***
- 2. In order to make auto DLS works properly, please make sure Date & Time are set correctly..***
- 3. The clock will quit from the setting mode automatically without any changing with setting if you hold it in the mode more than 70 seconds.***

**Ingrams Time Systems Pty Ltd**

12 / 21 Eugene Terrace

Ringwood Victoria 3134

Ph: (03) 9876 0066 Fax: (03) 9876 0055